FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT	FIELD REQUIREMENT
						<u>Bundled</u>	Direct Access
						<u>Service</u>	<u>TO</u>
						TO Direct Access	Bundled
						Direct Access Process # 1	<u>Service</u> Process # 2
						Flocess # 1	Process # 2
						Required = R	Required = R
						Conditional = C	Conditional = C
						Optional = O	Optional = O
1	Date MIRN Sent	Date MIRN Sent	<u>10</u>		YYYY/MM/DD	<u>R</u>	<u>R</u>
<u>+</u> 4 <u>2</u>	UDC Name	UDC where meter work was completed	30	<u>C</u>	1111///////////////////////////////////	<u>R</u>	<u>R</u>
		—— Ajo		_		_	<u> </u>
		APS: Arizona Public Service Company					
		CUC: Citizens Utilities Company					
		DVEC:Duncan Valley Electric Cooperative Inc					
		GCEC: Graham County Electric Cooperative Inc					
		MEC: Mohave Electric Cooperative Inc					
		Morenci NEC: Navapache Electric Cooperative Inc					
		SRP: Salt River Project					
		TEP: Tucson Electric Power Company					
		TRICO: Trico Electric Cooperative Inc					
3	Meter Activity	Type of work performed at the site	<u>1</u>	<u>C</u>	<u>1</u>	<u>R</u>	<u>R</u>
		1 = Meter Exchange remove and set a meter at the same			2		
		time.			<u>3</u>		
		2 = Upgrade Meter modify functionality of existing meter with			1 2 3 4 5		
		<u>IDR, DPI and/or modem</u> 3 = Meter Removal remove a meter without installing another			<u>5</u>		
		meter					
		4 = Reprogramming/Reconfiguring changes to existing					
		meter at site					
		5 = Meter Upgrade/Reprogramming upgrading and					
		programming to the existing meter at the site					
<u>24</u>	Transaction Ref #	Unique transaction identification number assigned by the	<u>30</u>	<u>C</u>		<u>R</u>	<u>R</u>
		originator of this transaction					
3	Exchange Meter	Removing and setting a meter at the same time			X	C	
	Upgrade Meter	Modify functionality of existing meter with IDR, DPI and/or a modem			X	C	
	Meter Removal	Removing a meter without installing another meter			X	C	
	Meter	Reprogramming/reconfiguring the meter at the site			X	C	
	Reprgrm/Reconfig						

MIRN DATA ELEMENTS ______Sample – proposed changes for <u>10/25/00</u> 11/29/00

TYPE: C = Character | I = Integer

			TYPE: _(C = Charact	er _I = Integer		
#	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
	Date MIRN sent	Date MIRN Sent YYYYDDMM			YYYY/MM/DD	R	
<u>5</u>	Lost kW	Calculated kW or displayed instantaneous kW for meters out of the socket 15 minutes or greater	<u>6</u>	<u>C</u>		<u>C</u>	<u>C</u>
<u>6</u>	DASR Tracking #	Unique number assigned by the originator submitting the DASR (Direct Access Service Request). First 13 (9 + 4) digits are the originator's Duns # followed by 9 user-specified digits. All future communication about this transaction will contain this tracking number	<u>22</u>	<u>C</u>		<u>R</u>	R
7	<u>UNI –</u>	Unique permanent identification number assigned to each	<u>19</u>	<u>C</u>		<u>R</u>	<u>R</u>
	<u>Universal Node ID</u>	service delivery point of the UDC's distribution network					
<u>8</u>	Service Address	Address of the metering site	<u>50</u>	<u>C</u>		<u>R</u>	<u>R</u>
<u>9</u>	<u>Customer Name</u>	Name of Customer responsible for account	<u>42</u>	<u>C</u>		<u>R</u>	<u>R</u>
5 <u>10</u>	Work Completion Date	Date that the meter work occurred	<u>10</u>		YYYY/MM/DD	R	<u>R</u>
6 <u>11</u>	New Meter Set Time	Set time is based on specific meter activity: Exchange: Time reflects when new meter isinstalled Upgrade: Time reflects when meter upgrade is complete Removal: Time reflects when meter is removed and no new meter is installed Reprogram: Time reflects when the meter was reprogrammed	7		Time will convert to military time. i.e. 00:00 space "p". Tab off field to convert	R	<u>R</u>
12	Existing Meter Removal Time	Time reflects when the meter was removed	7		Time will convert to military time. i.e. 00:00 space "p". Tab off field to convert	R	R
7 <u>13</u>	ESP	Acronym ID for ESP submitted on DASR	<u>30</u>	<u>C</u>		R	<u>R</u>
8 <u>14</u>	MSP	Acronym ID for MSP submitted on DASR	30	C		R	C
8	UNI - Universal Node ID	Unique permanent identification number assigned to each service delivery point of the UDC's distribution network				R	
10 15	UDC Account Number	UDC account number for customer	<u>20</u>	<u>C</u>		R	<u>R</u>

MIRN DATA ELEMENTS ______Sample – proposed changes for 10/25/00 11/29/00 _____TYPE: _C = Character _I = Integer

	I		_	S = Characte			
#	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	<u>FORMAT</u>	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
11	Service Address	Address of the metering site				R	
12 16	City/Town/County	City/Town/County in which the metering site is located	30	<u>C</u>		R	R
13	Customer Name	Name of Customer responsible for account				R	
<u> 1417</u>	Business Name	Business name of the account, if different from customer name	<u>50</u>	<u>C</u>		R <u>C</u>	C
15 18a	Existing /new AZ Meter Number	UDC meter number Unique number assigned by the UDC. Number located on face plate of meter	<u>17</u>	<u>C</u>		R	<u>R</u>
<u>18b</u>	New Meter AZ Meter Number	Unique number assigned by the UDC. Number located on face plate of meter	<u>17</u>	<u>C</u>		<u>R</u>	<u>O</u>
<u>19a</u>	Existing Meter Serial Number	Serial number on face plate of meter	<u>10</u>	<u>C</u>		<u>R</u>	<u>R</u>
<u>19b</u>	New Meter Serial Number	Serial number on face plate of meter	<u>10</u>	<u>C</u>		<u>R</u>	<u>O</u>
16	Existing/new Meter Serial Number	Serial number on face plate					
<u>20a</u>	Existing Meter AZ Kvarh Meter Number	Unique number assigned by the UDC. Number located on face plate of meter	<u>17</u>	<u>C</u>		<u>C</u>	<u>C</u>
<u>20b</u>	New Meter AZ Kvarh Meter Number	Unique number assigned by the UDC. Number located on face plate of meter	<u>17</u>	<u>C</u>		C	<u>O</u>
17	Existing/new AZ Kvarh Meter Number	UDC Kvarh meter number				C	
<u>21a</u>	Existing Meter Kvarh Meter Serial Number	Serial number on face plate of meter	<u>10</u>	<u>C</u>		C	<u>O</u>
<u>21b</u>	New Meter Kvarh Meter Serial Number	Serial number on face plate	<u>10</u>	<u>C</u>		<u>C</u>	<u>O</u>
18	Existing/new Kvarh Meter Serial Number	Serial number on face plate				C	
19	Exisitng/new meter date display				use leading zero	C=existing R=new	
<u>22a</u>	Existing Meter – Meter Date Display #	Display segment for the meter date	2	<u>C</u>		C	<u>C</u>

MIRN DATA ELEMENTS ______Sample – proposed changes for 10/25/00 11/29/00 _____TYPE: _C = Character _I = Integer

			TYPE: _(<i>z</i> = Charact	er _I = Integer		
FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
<u>22b</u>	Existing Meter – Meter Date Read	Display meter date when the meter is removed/installed	<u>10</u>	C	No formatting, should be exactly what is on display	<u>C</u>	<u>C</u>
<u>22c</u>	New Meter – Meter Date Display #	Display segment for the meter date	<u>2</u>	<u>C</u>		<u>C</u>	<u>O</u>
<u>22d</u>	New Meter – Meter Date Read	Display meter date when the meter is removed/installed	<u>10</u>	C	No formatting, should be exactly what is on display	<u>C</u>	Q
<u>23a</u>	Existing Meter – Meter Time Display #	Display segment for the meter time	<u>2</u>	<u>C</u>		<u>C</u>	<u>C</u>
<u>23b</u>	Existing Meter – Meter Time Read	Display meter time when the meter is removed/installed	10	C	No formatting, should be exactly what is on display	<u>C</u>	<u>C</u>
<u>23c</u>	New Meter – Meter Time Display #	Display segment for the meter time	2	<u>C</u>		<u>C</u>	<u>O</u>
<u>23d</u>	New Meter – Meter Time Read	Display meter time when the meter is removed/installed	<u>10</u>	<u>C</u>	No formatting, should be exactly what is on display	<u>C</u>	Ō
19a	Exisitng/new meter date read	Internal meter date when the meter is removed/installed			no formatting, should be exactly what is on display		
20	Existing/new meter time display				use leading zero		
20a	Existing/new meter time read	Internal meter time when the meter is removed/installed			no formatting, should be exactly what is on display		
<u>24a</u>	Existing Meter – Total kWh Read Display #	Display segment for total kWh	2	<u>C</u>		<u>C</u>	<u>R</u>

			TYPE: _(C = Charact	er _I = Integer		
FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
<u>24b</u>	Existing Meter – Total kWh Read	Five (5) dial kWh read of the meter at the time of removal/installation.	<u>5</u>	<u>C</u>	Fill all values shown on display	R	R
<u>24c</u>	New Meter – Total kWh Read Display #	Display segment for total kWh	<u>2</u>	<u>C</u>		<u>R</u>	Q
<u>24d</u>	New Meter – Total kWh Read	Five (5) kWh read of the meter at the time of removal/installation.	<u>5</u>	C	Fill all values shown on display	B	Ō
<u>25a</u>	Existing Meter – Total kW Read Display #	Display segment for total kW	2	<u>C</u>		<u>C</u>	<u>C</u>
<u>25b</u>	Existing Meter – Total kW Read	Total demand read of the meter at the time of removal/installation. Fill all values shown on display. TWO decimal places only	<u>6</u>	<u>C</u>	Fill all values shown on display	<u>C</u>	<u>C</u>
<u>25c</u>	New Meter – Total kW Read Display #	Display segment for total kW	<u>2</u>	<u>C</u>		<u>R</u>	<u>O</u>
<u>25d</u>	New Meter – Total kW Read	Total demand read of the meter at the time of removal/installation. Fill all values shown on display. TWOdecimal places only	<u>6</u>	C	Fill all values shown on display	R	Ō
<u>26a</u>	Existing Meter – Total Kvarh Reads Display #	Display segment for the Kvarh read	2	<u>C</u>		<u>C</u>	<u>C</u>
<u>26b</u>	Existing Meter – Total Kvarh Reads	Total Kvarh read of the meter at the time of removal/installation.	<u>5</u>	IO	Fill all values shown on display	<u>C</u>	<u>C</u>
<u>26c</u>	New Meter – Total Kvarh Reads Display #	Display segment for the Kvarh read	2	<u>C</u>		<u>C</u>	<u>C</u>
26d	New Meter – Total Kvarh Reads Existing/new total	Total Kvarh read of the meter at the time of removal/installation	<u>5</u>	C	Fill all values shown on display use leading	<u>C</u>	<u>C</u>
	kWh read display				zero		
21a	Existing/new total kWh read -read	Total kWh read of the meter at the time of removal/installation			use leading zero	R	

MIRN DATA ELEMENTS ______Sample – proposed changes for 10/25/00 11/29/00 TYPE: _C = Character _I = Integer

			ITPE: _C		erı = ınteger		
FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C
						Optional = O	Optional = O
22	Existing/new total kW read display				use leading zero		
22a	Existing/new total kW read -read	Total demand read of the meter at the time of removal/installation			use leading zero		
23	Existing/new total Kvarh read display				use leading zero	C	
23a	Existing/new total Kvarh read -read	Total Kvarh read of the meter at the time of removal/installation			use leading zero	£	
24-35	Existing/new TOU read display 1-12				use leading zero	C	
24-35	Existing/new TOU read -read 1-12	Time of Use read of the meter at the time of removal/installation			use leading zero	C	
<u>27-</u>	Existing Meter – TOU	Display segment for TOU reads	2	<u>C</u>		C	<u>C</u>
<u>38a</u>	Read Display #	The aftherward of the content of the fire of	_	_	E30 = 0 1	0	
<u>27-</u> <u>38b</u>	Existing Meter – TOU Read	Time of Use read of the meter at the time of removal/installation.	<u>5</u>	<u>C</u>	<u>Fill all values</u> <u>shown on</u> <u>display</u>	<u>C</u>	<u>C</u>
27- 38c	New Meter – TOU Read Display #	Display segment for TOU reads	2	<u>C</u>		<u>C</u>	O
27- 38d	New Meter – TOU Read	Time of Use read of the meter at the time of removal/installation.	<u>5</u>	C	Fill all values shown on display	C	Q
36 39	CT Ratio (PHS 1-2-3)	Current Transformer Ratio between primary and secondary current. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
37 40	CT Type _(PHS 1-2-3)	CT type listed on face plate. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
<u>3841</u>	CT ID# _(PHS 1-2-3)	Unique number assigned by UDC. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
<u>3942</u>	CT Serial # _(PHS 1-2-3)	Manufacturer serial number listed on face plate. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
4043	CT use (in/out)	Indoor or Outdoor use of CT. FOR NEWLY INSTALLED EQUIPMENT ONLY	3	<u>C</u>	in or out	С	<u>O</u>
41 <u>44</u>	VT Ratio (PHS 1-2-3)	Voltage Transformer Ratio between primary and secondary voltage. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>

MIRN DATA ELEMENTS ______Sample – proposed changes for <u>10/25/00 11/29/00</u>

TYPE: _C = Character _I = Integer

=:=: 5	141511	EIELD DEELNITION			er _i = integer		EIEL B
FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
4 <u>2</u> 45	VT Type _(PHS 1-2-3)	VT type listed on face plate. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	C		С	<u>O</u>
43 <u>46</u>	VT ID # (PHS 1-2-3)	Unique number assigned by UDC. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
44 <u>47</u>	VT Serial # (PHS 1-2-3)	Manufacturer serial number listed on face plate. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
4 <u>5</u> 48	VT use (in/out)	Indoor or Outdoor use of VT. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>3</u>	<u>C</u>	in or out	С	<u>O</u>
46 <u>49</u>	Rated Primary Amps	Maximum ampacity at which CTs can accurately measure. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
47 <u>50</u>	Primary Volts	Primary voltage upon which the performance specifications of a voltage transformer are based. FOR NEWLY INSTALLED EQUIPMENT ONLY	<u>10</u>	<u>C</u>		С	<u>O</u>
48	Add'l Info / Remarks	Additional pertinent information on the removed/installed meter, such as specialized equipment and any general comments				Đ	
4951	Meter Location:	Any changes to where meter is located at site	<u>250</u>	<u>C</u>		С	<u>O</u>
50 <u>52</u>	Mtr Reading Instructions	Any changes or additional information for locating meter, site surroundings and access issues	250	C		С	<u>O</u>
<u>53</u>	Add'l Info / Remarks	Additional pertinent information on the removed/installed meter, such as specialized equipment and any general comments	<u>250</u>	C		<u>O</u>	Q
51	IDR Unit of Measure	Channel numbers and related units of measurement					
52 54	Manufacturer	Manufacturer of the Meter	<u>7</u>	<u>C</u>		R	<u>O</u>
53 55	Model/Meter Type	Meter type listed on the face plate	<u>10</u>	<u>C</u>		R	<u>O</u>
5 4 <u>56</u>	Meter Form	Meter form that contains condensed meter characteristics for the meter	3	<u>C</u>		R	<u>O</u>
55 57	Meter Class	Maximum of the watthour meter load range in amperes	3	<u>C</u>		R	<u>O</u>
56 58	Meter Voltage	Voltage of the meter. Note if auto ranging	9	<u>C</u>	Auto Or xxx/xxx	R	Ō
57 59	KYZ Output	Number of external output pulses per disk revolution or equivalent (R/I, M/P, etc)	<u>5</u>	<u>C</u>	Required if Ke exists	С	<u>O</u>

MIRN DATA ELEMENTS ______Sample – proposed changes for <u>10/25/00 11/29/00</u>

TYPE: _C = Character _I = Integer

			ITPEC	= Charact	er _I = Integer		
FIELD #	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access	FIELD REQUIREMENT Direct Access TO Bundled Service
						Process # 1	Process # 2
						Required = R Conditional = C Optional = O	Required = R Conditional = C Optional = O
58 <u>60</u>	Most recent calibration test date	Last date meter was tested/calibrated.	<u>10</u>		YYYY/MM/DD	R	Q
59 61	Optical Port (y/n)	Yes value indicates meter has optical port for communication with meter and other devices	<u>1</u>	<u>C</u>	Y or N	<u>C</u>	<u>O</u>
60 62	# Display Segments	Number of meter read display segments on solid state meter	2	<u>C</u>		<u>C</u>	<u>O</u>
61 63	Program ID Name	Software program name with which the meter is programmed	2	<u>C</u>		<u>C</u>	0
6264	Meter Pulse Constant	Watthour per pulse value programmed into a solid state	6	C		C	<u>O</u>
	Ke	meter/recorder. Ke=Kh X R/I divided by 1000. If there is an	_	_			_
		internal scaling factor, sum of above formula X scaling factor					
63 65	# of IDR Channels	Number of IDR channels programmed_utilized_for the meter at the site	<u>2</u>	<u>C</u>	Field 66 and 67 are required if value in this field	<u>C</u>	Q
<u>66</u>	UOM/Channel #	Utility standard code for units of measurement: 01 = KWH 03 = KVARH Channel # unit of measurement is on	<u>5</u>	<u>C</u>	<u>xx/xx</u>	R If field 65 is filled inC	R If field 65 is filled inQ
<u>67</u>	UOM/Channel #	Utility standard code for units of measurement: 01 = KWH 03 = KVARH Channel # unit of measurement is on	<u>5</u>	CI	xx/xx	R If field 65 is filled in	R If field 65 is filled in
<u>68</u>	External Device(y/n)	Yes value indicates meter has external device attached	<u>1</u>	<u>C</u>	Y or N	<u>C</u>	<u>O</u>
<u>69</u>	External Device Type	Device type listed on face plate	<u>8</u>	<u>C</u>		<u>C</u>	<u>O</u>
70	UOM/Channel #	Utility standard code for units of measurement:	<u>5</u>	<u>C</u>	xx/xx	<u>C</u>	<u>O</u>
		01 = KWH 03 = KVARH Channel # unit of measurement is on					
<u>71</u>	UOM/Channel #	Utility standard code for units of measurement: 01 = KWH 03 = KVARH Channel # unit of measurement is on	<u>5</u>	<u>C</u>	xx/xx	<u>C</u>	Q
6472	kWh number of dials	Number of visual kWh dials	1	<u>C</u>		R	<u>O</u>
65 <u>73</u>	kW number of dials	Number of visual kW dials including decimal place	1	C		C	<u> </u>
	1		·		1	<u> </u>	<u> </u>

MIRN DATA ELEMENTS ______Sample – proposed changes for 10/25/00 11/29/00 TYPE: _C = Character _I = Integer

6674	kW decimal values	Placement of the decimal point on kW display	· · · · <u>-</u> · _ ·	I	ter _i = integer	С	0
FIELD	MIRN	FIELD DEFINITION	Field	Field	FORMAT	FIELD	FIELD
	FIELD	FIELD DEFINITION	Size		FURIMAT	REQUIREMENT	REQUIREMENT
<u>#</u>	NAME		<u>312e</u>	<u>Type</u>			
	NAME					Bundled	Direct Access
						<u>Service</u>	<u>TO</u>
						<u>TO</u>	Bundled
						Direct Access	<u>Service</u>
						Process # 1	Process # 2
						Required = R	Required = R
						Conditional = C	Conditional = C
						Optional = O	Optional = O
						<u>optional – o</u>	optional = o
67 75	Kvarh number of	Number of visual Kvarh dials	<u>1</u>	<u>C</u>		С	<u>O</u>
-	dials						
68 76	Meter Disk Constant	Number of watthours represented by one revolution of the disk	<u>4</u>	<u>C</u>		R	<u>O</u>
00777	Kh	include decimal place					
69 777	Meter Register	Multiplier applied to the register reading to obtain	2	<u>C</u>		С	<u>O</u>
7070	Constant Kr Register Ratio	kilowatthours (does not include CT, VT ratios) Number of revolutions of the gear meshing with the worm or	10	C		R	<u>O</u>
70 78	Register Ratio		<u>10</u>	<u>U</u>		K	<u>U</u>
		pinion on the rotating element for one revolution of the first dial pointer					
71 79	Meter Multiplier	Multiplier applied to the register reading to obtain	6	C	No leading	R	<u>O</u>
7 + <u>1 - 0</u>	Weter Wattpilet	kilowatthours including the CT and VT ratios		_	zeros		<u> </u>
80	Internal Scaling	PENDING DISCUSSION ON 11/29/00					
	Factor						
<u>81</u>	Kwhc	PENDING DISCUSSION ON 11/29/00					
72 82	XFMR Loss Comp	Yes value indicates compensation incorporated in actual	<u>1</u>	<u>C</u>	Y or N	R	0
	(y/n)	meter programming					
73 83	Number of service	Wires for the service	<u>1</u>	<u>C</u>	use leading	R	<u>O</u>
	wires				zero		
74 84	Delta/Wye	Transformer configuration of the service	<u>1</u>	<u>C</u>	D or ₩ <u>Y</u>	С	<u>O</u>
		For 3 phase/3 wire, use Delta			SRP service		
		For 3 phase/4 wire, use Delta or Wye			area use Y		
		(choose the appropriate configuration)			instead of W		
75 85	Service Voltage	Voltage of the service point	<u>10</u>	<u>C</u>		R	<u>O</u>
76 86	Customer Lock Cut	Yes value indicates customer lock was cut	<u>1</u>	<u>C</u>	Yor N	R	<u>O</u>
	(y/n)			_		_	
77 87	UDC lock cut (y/n)	Yes value indicates UDC lock was cut	1	<u>C</u>	Yor N	R	<u>O</u>
78 88	Meter Phone # /LSS	Telephone number attached to the meter or recorder used to	<u>15</u>	<u>C</u>	no formatting,	С	<u>O</u>
	Port	upload meter site information			i.e.		
					1112223333#		
			<u> </u>		44		_

MIRN DATA ELEMENTS ______Sample – proposed changes for 10/25/00 11/29/00

			TYPE: _C = Character _I = Integer				
<u>89</u>	Communication Type	If applicable, use one of the following codes: C = Cell Phone S = Shared phone line D = Dedicated phone line R = Radio communication	1	<u>C</u>	C S D R	<u>R</u>	Ō
79	Cell Phone (y/n)	Yes value indicates meter communication via cell phone .			Y or N	R	
#	MIRN FIELD NAME	FIELD DEFINITION	Field Size	Field Type	FORMAT	FIELD REQUIREMENT Bundled Service TO Direct Access Process # 1 Required = R Conditional = C Optional = O	FIELD REQUIREMENT Direct Access TO Bundled Service Process # 2 Required = R Conditional = C Optional = O
80	Shared Phone line (y/n)	Yes value indicates meter is sharing lines with other devices i.e. fax machine, handset, etc			Yor N	R	
81	Dedicated Phn line (y/n)	Yes value indicates line dedicated to meter communication			Y or N	R	
<u>82</u>	Radio Comm (y/n)	Yes value indicates meter has a radio communicator that			Y or N	R	